


**BRITE BOX 4L.DRL WITH DRIVING LIGHT SLAVE WIRE  
SUGGESTED INSTALLATION SCHEMATIC**

SLAVE WIRE IS SINGLE PURPLE WIRE COMING FROM BRITE BOX.

IT IS **HIGHLY RECOMMENDED** THAT YOU INSTALL **DASH MOUNTED SWITCH** AS PER SCHEMATIC SO YOU CAN CANCEL DRIVING LIGHT OPERATION FOR CITY DRIVING. IF NO MASTER SWITCH IS INSTALLED, DRIVING LIGHTS WILL ALWAYS LIGHT WHENEVER HIGH BEAMS ARE SELECTED!

**IMPORTANT NOTE: SLAVE WIRE IS A NEGATIVE OUTPUT WIRE THAT IS DESIGNED TO OPERATE A RELAY. ANY ATTEMPT TO HOOK DRIVING LIGHTS DIRECTLY TO THIS WIRE WILL CAUSE INTERNAL DAMAGE TO UNIT THAT IS NOT COVERED UNDER WARRANTY!**



**NOTE: FUSE THIS LEAD!**  
**FAILURE TO INSTALL FUSE CAN RESULT IN FIRE IN CASE OF SHORT CIRCUIT!**  
**FUSE VALUE DEPENDS ON SPECIFIC DRIVING LIGHTS USED.**